

# FXLuminaire

## FX LUMINAIRE



1940 Diamond Street

San Marcos, CA 92078

Main: 760-744-5240

Technical Support: 760-591-7383

www.fxl.com



**LCM-LV DETAIL ISOMETRIC**

### **DETAILS:**

**TYPE:** LOW VOLTAGE

**MODEL NO:** LCM-LV


**MAX LOAD:** 60W/5A

**SUPPORTS:** INCANDESCENT

**NOTES:** ALTERNATIVE LV POWER SOURCE REQUIRED

### **NOTES:**

1. ATTACH ONLY LAMPS TO THE OUTPUT OF THE LV CUBE.
2. ATTACH ONLY DIMMABLE LAMPS TO THE OUTPUT.
3. DO NOT USE THE LUXOR AS BOTH POWER AND CONTROL IF AN INCANDESCENT FIXTURE IS ATTACHED TO THE CUBE'S OUTPUT.
4. DO NOT APPLY MORE THAN 15VAC TO THE INPUT POWER LEADS.
5. DO NOT ATTACH MORE THAN 60W OF LAMPS TO THE OUTPUT OF THE LV CUBE.
6. USE ONLY WATERTIGHT CONNECTORS IN WET ENVIRONMENTS.
7. INSTALLATION TO BE COMPLETED IN ACCORDANCE WITH MANUFACTURER'S SPECIFICATIONS.
8. THIS DRAWING IS INTENDED FOR USE BY ARCHITECTS, ENGINEERS, CONTRACTORS, CONSULTANTS AND DESIGN PROFESSIONALS FOR PLANNING PURPOSES ONLY. THIS DRAWING MAY NOT BE USED FOR CONSTRUCTION.
9. ALL INFORMATION CONTAINED HEREIN WAS CURRENT AT THE TIME OF DEVELOPMENT BUT MUST BE REVIEWED AND APPROVED BY THE PRODUCT MANUFACTURER TO BE CONSIDERED ACCURATE.



## LUXOR CUBE

LOW VOLTAGE INCANDESCENT + 12V TRANSFORMER

NOT TO SCALE